

ATA	Partnumber	Highest EM P/N	Nomenclature	Model	Manual	Manufacturer	Inst to	Maintenance Level	Rating FAA EASA	R R 2 5 0	P T 6 6 A	P T 6 6 B	P T 6 6 T	P W 1 0 0	G T C P 8 5	C T 7	A/C Type
73	2524316		Fuel Control Unit	DP-F2	73-20-28	HONMONT	PT6A	Overhaul	C7		20						De Havilland Twin Otter
73	2524439		Fuel Control Unit	DP-F2	73-20-28	HONMONT	PT6A	Overhaul	C7		20						Embraer
73	3244723		Fuel Control Unit	DP-F2	73-20-08	HONMONT	PT6A	Overhaul	C7		41						Fairchild Dornier
73	3244738		Fuel Control Unit	DP-F2	73-20-13	HONMONT	PT6A	Overhaul	C7		45						LET L410
73	3244738		Fuel Control Unit	DP-F2	73-20-13	HONMONT	PT6A	Overhaul	C7		45A						Piaggio
73	3244738		Fuel Control Unit	DP-F2	73-20-13	HONMONT	PT6A	Overhaul	C7		45B						Pilatus
73	3244745		Fuel Control Unit	DP-F2	73-20-15	HONMONT	PT6A	Overhaul	C7		21						Piper Cheyenne
73	3244752		Fuel Control Unit	DP-F2	73-20-08	HONMONT	PT6A	Overhaul	C7		41						Piper Malibu Meridian
73	3244753		Fuel Control Unit	DP-F3	73-20-16	HONMONT	PT6A	Overhaul	C7		50						Raytheon Beech
73	3244755		Fuel Control Unit	DP-F2	73-20-08	HONMONT	PT6A	Overhaul	C7		41						Raytheon Beech King Air
73	3244769		Fuel Control Unit	DP-F2	73-20-13	HONMONT	PT6A	Overhaul	C7		45						Shorts
73	3244769		Fuel Control Unit	DP-F2	73-20-13	HONMONT	PT6A	Overhaul	C7		45A						
73	3244769		Fuel Control Unit	DP-F2	73-20-13	HONMONT	PT6A	Overhaul	C7		45B						
73	3244770		Fuel Control Unit	DP-F2	73-20-21	HONMONT	PT6A	Overhaul	C7		45B						
73	3244773		Fuel Control Unit	DP-F2	73-20-26	HONMONT	PT6A	Overhaul	C7		45R						
73	2524440		Main Fuel Control	DP-F2	73-20-31	HONMONT	PT6A	Overhaul	C7		27						
73	3244746		Main Fuel Control	DP-F2	73-20-23	HONMONT	PT6A	Overhaul	C7		25						
73	3244764		Main Fuel Control	DP-F2	73-20-24	HONMONT	PT6A	Overhaul	C7		45A						
73	3244768		Main Fuel Control	DP-F2	73-20-22	HONMONT	PT6A	Overhaul	C7		42						
73	3244771		Main Fuel Control	DP-F2	73-20-25	HONMONT	PT6A	Overhaul	C7		34						
73	3244775		Main Fuel Control	DP-F2	73-20-34	HONMONT	PT6A	Overhaul	C7		25						
73	3244775		Main Fuel Control	DP-F2	73-20-34	HONMONT	PT6A	Overhaul	C7		25A						
73	3244777		Main Fuel Control	DP-F2	73-20-27	HONMONT	PT6A	Overhaul	C7		135						
73	3244786		Main Fuel Control	DP-F2	73-20-43	HONMONT	PT6A	Overhaul	C7		27						
73	3244788		Main Fuel Control	DP-F2	73-20-44	HONMONT	PT6A	Overhaul	C7		135						
73	3244789		Main Fuel Control	DP-F2	73-20-32	HONMONT	PT6A	Overhaul	C7		35F						
73	3244791		Main Fuel Control	DP-F2	73-20-33	HONMONT	PT6A	Overhaul	C7		35F						
73	3244799		Main Fuel Control	DP-F2	73-20-35	HONMONT	PT6A	Overhaul	C7		40						
73	3244802		Main Fuel Control	DP-F2	73-20-38	HONMONT	PT6A	Overhaul	C7		62						
73	3244809		Main Fuel Control	DP-F2	73-20-36	HONMONT	PT6A	Overhaul	C7		25D						
73	3244831		Main Fuel Control	DP-F2	73-20-45	HONMONT	PT6A	Overhaul	C7		62						
73	3244834		Main Fuel Control	DP-F2	73-20-46	HONMONT	PT6A	Overhaul	C7		34						
73	3244856		Main Fuel Control	DP-F2	73-20-54	HONMONT	PT6A	Overhaul	C7		62						
73	3244872		Main Fuel Control	DP-F2	73-20-64	HONMONT	PT6A	Overhaul	C7		27						
73	3244897		Main Fuel Control	DP-F2	73-20-78	HONMONT	PT6A	Overhaul	C7		114A						
73	4138005		Main Fuel Control	DP-F2	73-20-52	HONMONT	PT6A	Overhaul	C7		25C						
73	4138010		Main Fuel Control	DP-F2	73-20-35	HONMONT	PT6A	Overhaul	C7		40						
73	4138014		Main Fuel Control	DP-F2	73-20-35	HONMONT	PT6A	Overhaul	C7		40						
73	2524167		PT Governor	AL-N1	73-20-29	HONMONT	PT6A	Overhaul	C7		20						
73	41380007		PT Governor	DP-F2	73-20-81	HONMONT	PT6B	Overhaul	C7		37						
73	2524381		Automatic Fuel Control	DP-F2	73-20-03	HONMONT	PT6T	Overhaul	C7		3						Bell / Agusta 212, 212 ASW
73	2524992		Automatic Fuel Control	DP-F2	73-20-03	HONMONT	PT6T	Overhaul	C7		3						412 HP, Bell AH-1T / AH-1J
73	3244712		Automatic Fuel Control	DP-F2	73-20-03	HONMONT	PT6T	Overhaul	C7		3						
73	3244717		Automatic Fuel Control	DP-F2	73-20-03	HONMONT	PT6T	Overhaul	C7		3						
73	3244721		Automatic Fuel Control	DP-F2	73-20-03	HONMONT	PT6T	Overhaul	C7		3						
73	3244733		Automatic Fuel Control	DP-F2	73-20-11	HONMONT	PT6T	Overhaul	C7		402						
73	3244735		Automatic Fuel Control	DP-F2	73-20-11	HONMONT	PT6T	Overhaul	C7		402						
73	3244737		Automatic Fuel Control	DP-F2	73-20-12	HONMONT	PT6T	Overhaul	C7		402						
73	2524998		Main Fuel Control	FD-AA1	73-20-02	HONMONT	PT6T	Overhaul	C7		3						
73	3244736		Main Fuel Control	FD-AA1	73-20-12	HONMONT	PT6T	Overhaul	C7		6						
73	3244883		Main Fuel Control	DP-F2	73-20-71	HONMONT	PT6T	Overhaul	C7		3D						
73	3244884		Main Fuel Control	FD-AA1	73-20-72	HONMONT	PT6T	Overhaul	C7		3D						
73	2524999		PT Governor	AL-N1	73-20-04	HONMONT	PT6T	Overhaul	C7		3						
73	3244885		PT Governor	AL-N1	73-20-69	HONMONT	PT6T	Overhaul	C7		3D						
73	3244881		Torque Control Unit	DP-F2	73-20-68	HONMONT	PT6T	Overhaul	C7		3						
73	3019536		Fuel Nozzle				PT6	Inspect/Test	C7								
73	3019537		Fuel Nozzle				PT6	Inspect/Test	C7								
73	3019754		Fuel Nozzle				PT6	Inspect/Test	C7								
73	3244853		Main Fuel Control Unit	P 108	73-20-53	HONMONT	PW100	Overhaul	C7		123						Dach 8, Fokker 50, ATR 72
73	3244858		Main Fuel Control Unit	P 108	73-20-55	HONMONT	PW100	Overhaul	C7		125B						
73	3244871		Main Fuel Control Unit	P 108	73-20-61	HONMONT	PW100	Overhaul	C7		127						
73	3244873		Main Fuel Control Unit	P 108	73-20-65	HONMONT	PW100	Overhaul	C7		127A/B						
49	380256-1-1	380256-1-1	Engine, APU		49-22-53	HONPH	GTCP85	Overhaul	B3					98D			MD80, 737
49	381276-1	381276-2	Engine, APU		49-21-83	HONPH	GTCP85	Overhaul	B3					98DHF			
49	381276-3	381276-4	Engine, APU		49-26-71	HONPH	GTCP85	Overhaul	B3					98DHF			
49	3800368-1	3800368-1	Engine, APU		49-25-57	HONPH	GTCP85	Overhaul	B3					98DCB			
49	380428-10	380428-12	Engine APU		49-25-41	HONPH	GTCP85	Overhaul	B3					129H,J,K			

ATA	Partnumber	Highest EM P/N	Nomenclature	Model	Manual	Manufacturer	Inst to	Maintenance Level	Rating		P W 1 0	G T C P 8 5	C T 7	A/C Type
									FAA	EASA				
54	7278005-533		Lower Eductor Shroud	54-40-10		Saab	340	Weld repair	SS					
54	7278300-521		Lower Eductor Shroud	54-40-10		Saab	340	Weld repair	SS					
54	7278005-536		Lower Eductor Shroud	54-40-10		Saab	340	Weld repair	SS					
54	7278005-527		Upper Eductor Shroud	54-40-10		Saab	340	Weld repair	SS					
72	6071197G01		Ejector Plenum	72-00-00		Saab	340	Weld repair	SS					
78	7271899-691		Mixing Duct	78-10-05-08		Saab	340	Weld repair	SS					
	7255456-511		Rodder Tip	SDS 018916		Saab	340	Weld repair	SS					
78	7271016-503		Mixing Duct	78-10-05-08		Saab	340	Weld repair	SS					
	212-061-202-009		Exhaust Duct	212-0950-29		Agusta	AB412	Weld repair	SS					Agusta Bell
	212-061-201-012		Ejector Assy	E-AB412-PT6T-2		Agusta	AB412	Weld repair	SS					
54	1379067H427		Guard	54-10-00		N/A	Jetstream	Weld repair	SS					Jetstream
78	1379049H401	137904H403	Stub Pipe	78-10-00		N/A	Jetstream	Weld repair	SS					
78	137-9048		Jet Pipe	78-10-00		N/A	Jetstream	Weld repair	SS					
	201-15-627		Exhaust Manifold	Drw202-15.627		FFA	FFA Bravo	Weld repair	SS					FFA Bravo
78	76305-07003-044		Exhaust Ejector	S76 78-10-00		N/A	Sikorsky	Weld repair	SS					Sikorsky
78	8444-1174-3321		Ejector L/H	DRB 2005-SA		N/A	Sikorsky	Weld repair	SS					
78	7608-07664-101		Tube	S76 78-10-00		N/A	Sikorsky	Weld repair	SS					
78	F1107-452-708		Jet Pipe	78-10-03		Fokker	Fokker 50	Weld repair	SS					Fokker 50
61	664006001/2		Spinner	CMM 61-10-35		Dowty	Fokker 50	Weld repair	SS					
78	F1107-452-401	F1107-452-403	Jet Pipe	78-10-03		Fokker	Fokker 50	Weld repair	SS					
	25-64-989-1		Vertical Restraint Frame	S21.DOI-0021		Fokker	Fokker 50	Weld repair	SS					
78	F8200-087-401	F8200-087-405	Engine Tail Pipe	CMM 78-10-02		Fokker	Fokker 50	Weld repair	SS					
78	F8551-003-401		Bleed Air Duct	CAS-21495		Fokker	Fokker 50	Weld repair	SS					
54	290-1501-1		Exhaust Cone	54-40-03		N/A	MD90	Weld repair	SS					MD90
49	4504358-1		Air Inlet Housing, APU	49-22-00		Hamilton Sundstrand	JAS 39	Plasma Spray	SS					JAS 39 Gripen
78	7378101-541		Exhaust Pipe	AMM 78-21-10		SAAB	2000	Weld repair	SS					SAAB 2000
79	9304000-315		Oil Cooler	CMM 79-25-02		AMATEK	SAAB 2000	Weld repair	SS					SAAB 2000
57	170-39321-003		Flap Track Rail	ETD2010-170/02734		Embraer	170	Weld repair/Plasma	SS					Embraer 170
78	5171-1,5172-1,5173-1		Tailpipe (Nozzle)	T.O. 1H-412-5033-99-6		Bell	412	Weld repair	SS					Bell 412
78	5170-1		Suppressor	T.O. 1H-412-5033-99-6		Bell	412	Weld repair	SS					Bell 412
49	1911761-105		APU Elbow Duct Assy	Boeing BNI-12-0029-03B		Senior Aerospace	Boeing 717	Weld repair	SS					Boeing 717
54	D5461018600200/300		Cover	Airbus CMM		Airbus	320	Weld repair	SS					Airbus 320
52	F5106-050-401		Cap Ground Wheel	CAS-33027-SXGTKP		Fokker	Fokker 50	Weld repair	SS					Fokker 50
36	F8551-020-405		Bleed Air Duct	CAS-31772-L77BKT		Fokker	Fokker 50	Weld repair	SS					Fokker 50
71	5552250-36		Inlet Assy RH	Model 550 MM 71-11-00		Cessna	Cessna 550	Weld repair	SS					Cessna 550
32	5009237		Main Wheel Subassy	Main Whell Assy 5010488		SAAB	SAAB340	Machining	SS					SAAB340
71	214-063-210-153	214-063-210-157	Duct Assy	BHT-214ST-CR&O 71-00-00		Bell	Bell 214ST	Weld repair	SS					Bell 214ST
	2451000-1		Engine Mount	Service Manual 17-69-17-70		Cessna	172RG	Weld repair	SS					Cessna 172RG
78	F1107-452-411	F1107-452-412	Jet Pipe	78-10-03		Fokker	Fokker 50	Repair	SS					Fokker 50
	7371600-821		Upper/mid duct	2000XPS032605		GKN Aerospace	Unk	Repair	SS					Unk
78	7378101-541		Exhaust Pipe	78-21-10		SAAB	Unk	Repair	SS					Unk
	7357862-009		Bracket	SRM 51-20-10-002		SAAB	Unk	Repair	SS					Unk
78	F1107-452-707		Jet Pipe	1978-10-03		Fokker	Fokker 50	Repair	SS					



2013-04-28 REV. 0

ATA	Partnumber	Highest EM P/N	Nomenclature	Model	Manual	Manufacturer	Inst to	Maintenance Level	Rating FAA EASA	R 2 5 0	P T 6 A	P T 6 B	P T 6 T	P W 1 0 0	G T C P 8 5	C T 7	A/C Type
-----	------------	-------------------	--------------	-------	--------	--------------	------------	----------------------	--------------------	------------------	------------------	------------------	------------------	-----------------------	----------------------------	-------------	----------
